

Part # TABG8002

1978-87 GM G-Body Floor Insulation and Sound Deadener Kit



Rear

Installation Directions:

- 1. Clean any dirt, debris, or grime from the intended installation area using a degreasing agent.
- 2. Allow intended installation area adequate time to dry.
- **3.** Remove the kit from its packaging, and dry fit the components allowing you to see exactly how the product will be placed for final installation.
- **4.** Now you are ready to install. Remove the protective layer exposing the adhesive on your first piece applying it to its final position, using light pressure.
- **5.** Repeat step 4 for each individual component until the full kit is installed.